# **Craft Jet Heat Transfer Paper**

For Dark Fabric - Blue Line

## **Instructions**

#### **Compatible Ink Systems**

- Desktop inkjet printers (aqueous ink)
- Markers
- Crayon
- NOT COMPATIBLE WITH TONER/LASER PRINTERS

#### **Prepare Image**

- Print REGULAR orientation (do not reverse/flip/mirror)
- 2. Print/draw on non-glossy side (un-lined)
- 3. Cut around image if desired

### **Transfer Image - Heat Press**

- 1. Preheat press to 375°F
- 2. Pre-press garment for 3-5 seconds to release moisture and remove wrinkles
- 3. Peel liner from back of printed transfer
- 4. Place printed transfer onto the garment, print side up
- 5. Cover transfer with parchment paper
- 6. Press for 25 seconds with medium to high pressure
- 1. Peel parchment paper cold (wait 2 minutes) or hot (wait 5 seconds). For best colour retention during washing, peel hot.

#### Transfer Image - Iron

- 2. Preheat iron to the "cotton" setting (do not use steam)
- Make sure you have a hard, smooth pressing surface covered with a layer of fabric (such as a pillowcase. DO NOT USE AN IRONING BOARD
- 4. Pre-iron garment to release moisture and remove wrinkles
- 5. Peel liner from back of printed transfer
- 6. Place printed transfer onto the garment, print side up
- 7. Cover transfer with parchment paper
- 8. Using FIRM, STEADY pressure, holding iron with both hands, and applying your body weight, iron on each area of the sheet for 20 seconds. Make sure to light the iron completely when moving to a new position.

- Continue this process until you have ironed the entire sheet. Be sure to cover all corners and edges.
- 9. If transferring several images on one sheet, it works best to iron all and then peel all.
- 10. Peel parchment paper cold (wait 2 minutes) or hot (wait 5 seconds). For best colour retention during washing, peel hot.

#### **Washing Instructions**

- 1. Turn garment inside out
- 2. Wash in cold water
- 3. Do not use bleach or bleach alternative detergents
- 4. Remove garment promptly from the washer (the colour may bleed if left in the washer)
- 5. Dry on LOW temperature

